




Пошаговое руководство по настройке приемников

Установка радио частот в приемниках EFIX





1. Подключите приёмник по Wi-Fi к ПК (пароль для доступа: **12345678**).
2. Введите в адресной строке браузера **http://192.168.1.1/set_en.html**
3. Чтобы загрузить имеющийся файл с таблицей частот (.cfg), нажмите на верхнюю кнопку «**Выберите файл**» и укажите путь расположения файла.

The screenshot shows a web browser window with the address bar displaying "192.168.1.1/set_en.html". Below the address bar, there is a button labeled "Выберите файл" (Select file) which is circled in red. To its right, the text "Файл не выбран" (File not selected) is visible. Below this, there is an "Upload" button. Further down, there are three buttons: "Active Pass-through to GNSS BOARD", "Active Pass-through to Radio", and "Inactivate Pass-through". Below these buttons, the text "Type of Tilt Sensor: N/A" is displayed. At the bottom, there is another "Выберите файл" button (also circled in red) with "Файл не выбран" to its right, and an "Update" button below it.

4. Нажмите Upload для загрузки файла.

The screenshot shows the same web browser window as before, but now the "Выберите файл" button is labeled with the filename "radio_ch..._Rus.cfg". The "Upload" button below it is circled in red. The rest of the interface, including the "Active Pass-through" buttons, "Type of Tilt Sensor: N/A" text, and the second "Выберите файл" button (which remains circled in red), is identical to the previous screenshot.